


## DS-D42MF2B

### LED Front Maintenance Tool



#### Introduction

DS-D42MF2B is an LED front maintenance Tool for LED modules installation and maintenance use. It can help simplify the LED module build and dismantle work . Maintenance at the front of screen, Modules, receiving card and power supply can be replaced at the front side of screen.

#### Features and Functions

- Front maintenance tool for disassembling LED display module
- Flexible installation
- Package with flight case, well protected
- Most used for front maintenance of small pixel pitch LED display
- Easy to use

#### Available Models

DS-D42MF2B



## SPECIFICATIONS

<b>Model</b>	<b>DS-D42MF2B</b>
<b>Dimensions</b>	<b>350*220*230mm</b>
<b>Material</b>	<b>N50 magnetic steel + ABS + Silica gel</b>
<b>Color</b>	<b>Black</b>
<b>Weight</b>	<b>2.9kg</b>
<b>Generation</b>	<b>Second Generation</b>
<b>Power</b>	<b>Lithium ion battery</b>
<b>Battery capacity</b>	<b>3000mah</b>

CONTACT US



Headquarters

No.379 Qianmo Road, Binyang District

Hangzhou 310051, China

Tel: +86-571-8507-5000

Website: [www.hikvision.com](http://www.hikvision.com)



USA

1-800-391-9888

usa@hikvision.com



Europe

+31-20-486-8777

eu@hikvision.com



Middle East

+971-4-343-8888

me@hikvision.com



Russia

+7-495-241-9700

ru@hikvision.com



India

+91-11-2610-8800

in@hikvision.com



France

+33-1-69-35-8800

fr@hikvision.com



Spain

+34-91-787-1800

es@hikvision.com

### Headquarters

No.379 Qianmo Road, Binyang District

Hangzhou 310051, China

Tel: +86-571-8507-5000

Website: [www.hikvision.com](http://www.hikvision.com)

### Hikvision USA

Tel: 1-800-391-9888

usa@hikvision.com

### Hikvision Italy

Tel: +39-02-98-8777

eu@hikvision.com

### Hikvision Singapore

Tel: +65-6334-8800

sg@hikvision.com

### Hikvision Africa

Tel: +27-11-231-1177

af@hikvision.com

### Hikvision Europe

Tel: +31-20-486-8777

eu@hikvision.com

### Hikvision France

Tel: +33-1-69-35-8800

fr@hikvision.com

### Hikvision Oceania

Tel: +61-2-9594-8800

oc@hikvision.com

### Hikvision Hong Kong

Tel: +852-2151-1700

hk@hikvision.com

### Hikvision Middle East

Tel: +971-4-343-8888

me@hikvision.com

### Hikvision Spain

Tel: +34-91-787-1800

es@hikvision.com

### Hikvision Canada

Tel: +1-416-291-1800

ca@hikvision.com

### Hikvision Russia

Tel: +7-495-241-9700

ru@hikvision.com

### Hikvision Poland

Tel: +48-22-660-0100

pl@hikvision.com

### Hikvision Korea

Tel: +82-2-312-1800

kr@hikvision.com

### Hikvision India

Tel: +91-11-2610-8800

in@hikvision.com

### Hikvision GB

Tel: +44-20-800-0100

gb@hikvision.com

### Hikvision Brazil

Tel: +55-11-3318-8800

br@hikvision.com